

REMOTECONTROL IR6









i NOTICE

The REMOTECONTROL IR6 works with the following sensors from Tridonic:

- _ DALI MSensor 02, Article number: 28000897, 28000895, 28000896, 28000894
- _ DSI-SMART PTM, Article number: 28000878, 28000940, 28000877
- _ SMART Sensor 5-10DPI 19fe, Article number: 28000922, 28000929, 28000927, 28000928, 28000923, 28000926, 28000924, 28000925
- _ DALI MSensor 5DPI_14, Article number: 28000935, 28000936
- _ basicDIM Sensor 5DPI_14, Article number: 28000933, 28000934
- _ basicDIM ILD, Article number: 28000905
- _ MSensor G3 SFI 30 PIR 5DPI WH/BK, Article number: 28002384, 28002385, 28002386
- _ MSensor G3 SFI 30 PIR 10DPI WH, Article number: 28002119
- _ MSensor G3 SFI 30 PIR 16DPI WH, Article number: 28002234

REMOTECONTROL IR6

Functions

Icon	Designation	Description
	ON	Switch luminaires on Light regulation is deactivated
	OFF	Switch luminaires off
	Dim up	Increase current dimming level
	Dim down	Decrease current dimming level
	Automatic mode	Switch luminaire on or change to automatic mode Light regulation is started
	Set current light level	Store the brightness level currently measured by the sensor as target value for constant light control (press button >3 s)